

These are the instructions on how to set up your Psion 7 and Ericsson T39m with your ISP. Use the 'print' button to print off your set up instructions and then click 'close window' to continue.

print  close window 

The following information explains how to set up email under GPRS.

Orange GPRS Email Setup for Epoc 32

1. Tap the **Email** icon and tap the **Menu** key (Top left hand corner). Tap **Tools** then **Add New Account**. Tap **Email**.
2. Enter a name for your email account under **Account Name**, enter your name in the **Your Name** field and your own Email address in the **Email Address** field.
3. Tick the **Set As Default Account box**.
4. Tap the **Outgoing tab**. In the **Email (SMTP) Server** box enter: smtp.orange.net
5. Tap the **Incoming tab**. Enter (pop.orange.net) into the **POP3 Server box**.
6. In **Mailbox Login** enter your mailbox username. In the **Password** and **Confirm Password** boxes enter your password. Tap **OK**.
7. Tap **Open Mailbox**.
8. In the dialogue box that appears you should have your ISP connection selected, your modem and the ISP number that it will dial. Tap **OK** to proceed.
9. Your email will now download.

The following information explains how to set up GPRS on your phone and laptop/PDA.

Setup of Ericsson T39 to Psion 5MX using Infrared for GPRS

Configuring the Handset

1. Scroll to **Settings**.
2. Press **Yes** on **Data comm**.
3. Press **Yes** on **Data accounts**.
4. Press **Yes** on **Add account?**
5. Press **Yes** on **GPRS data**.
6. Type a name (Orange.net) for the GPRS connection and press **Yes**.
7. Press **Yes** on **APN**: enter the APN name (orangeinternet) .
8. Press **Yes** once entered.
9. Press **Yes** on **User ID**: enter the user ID (leave blank) .
10. Press **Yes** once entered.

11. Press **Yes** on **Password**: enter the password (leave blank) .
12. Press **Yes** once entered.
13. Press **Yes** on **Save?**
14. The GPRS data account will now be listed in **Data Accounts**.
15. Press **Yes** on the account you have created. Make a note of the CID number of the connection.

On the Psion 5MX

1. Double tap **Control Panel**.
2. Select **Modems**.
3. Tap **New**.
4. On the **Modem** tab enter the name of the modem as **Ericsson Infrared Modem**.
5. Set the **Speed** to: **57600**
6. Set **connect via** to **Infrared**.
7. Leave **Fax Class** on **Auto**.
8. On the **Options** tab: leave the settings at:
Loudspeaker in use: Never
Volume: Quiet
Pause time for “,” : 4
9. On the **Initialisation** tab set the **Init. (reset) String** to **AT&F**
10. **Data String** and **Fax String** leave blank.
11. On the **Advanced** tab, set **Flow Control** to: **Hardware (RTS/CTS)**
12. Tick the boxes next to **Terminal Detect** and **Carrier Detect** .
13. Set the **Modem Type** to **Mobile**.
14. Tap **OK** to return to the **Control Panel**.
15. Select **Internet**.
16. Select **New**.
17. Tap **OK** to set up an account based on standard settings.
18. On the **Service** tab set the **Name** to **GPRS**, select **Dial-up** as the **Connection type**.
19. Leave **Smart Dialling** blank, in **Standard Dial-up Number** enter ***99***X#** (where **X** is the CID number you noted in line 15 of *Configuring the handset*)
20. On the **Account** tab.
21. Choose between **Manual** login, where you will be prompted for a **username** and **password** when you make a connection, or enter your username and password in the in the **Username** and **Password** fields.
22. On the **Address** tab tick **Get IP address from server** and **Get DNS address from**

server.

23. On the **Login** tab: Leave all fields blank, tap **Advanced** .

24. Tick **Enable PPP extensions** and **Allow plain text authentication**.

25. Tap **OK** to close this screen.